

FOLLOW APPLICATION INSTRUCTIONS  
**NOTICE**  
FOLLOW APPLICATION INSTRUCTIONS



**HOWARD**  
**HOT PEEL**

**APPLICATION INSTRUCTIONS**

**Firm Pressure**

**370 degrees F**

- 1. Pre-heat garment 2 seconds.**
- 2. Apply transfer 10-12 seconds.**
- 3. Peel Hot!**