

FOLLOW APPLICATION INSTRUCTIONS
NOTICE
FOLLOW APPLICATION INSTRUCTIONS



PHOTOTRANS FOR WHITE

100% COTTON

APPLICATION INSTRUCTIONS

Medium Pressure

365 degrees F

- 1. Cut out design leaving approximately 1/8" border.**
- 2. Preheat garment for 5-10 seconds.**
- 3. Apply transfer ink side down for 12 seconds.**
- 4. Peel HOT.**