

FOLLOW APPLICATION INSTRUCTIONS
NOTICE
FOLLOW APPLICATION INSTRUCTIONS



SOFT FILM

APPLICATION INSTRUCTIONS

Light Pressure

330 degrees F

- 1. Remove protective tissue**
- 2. Pre-heat garment 5 seconds.**
- 3. Apply for 12-15 seconds.**
- 4. Peel HOT.**