

FOLLOW APPLICATION INSTRUCTIONS

**NOTICE**

FOLLOW APPLICATION INSTRUCTIONS



# **STRETCH PC**

## **APPLICATION INSTRUCTIONS**

**Light Pressure**

**330 degrees F**

- 1. Pre-heat garment 5 seconds.**
- 2. Apply transfer 10 seconds.**
- 3. Wait 5 seconds and peel warm.**
- 4. Cover with teflon sheet and press for 10 seconds.**
- 5. After garment has completely cooled, remove cover sheet.**